




Position	Amount	Type number	Description	PG
7	1	343432470	Housing w.cover	27
8	1	343394790	Switch slide	11
9	1	343394770	Pressure plate	11
10	1	342021670	Spring clip	11
11	1	343433250	Switch slide,R/L	11
12	1	316051650	Switch slide compl.	13
13	11	141113180	Self-tap. fill. h. screw	11
14	1	316053420	Gear-box compl.	41
15	1	310011160	Armature compl.,18 V	36
17	1	338059380	Rating plate	13
22	1	338129940	Indication label	12
30	1	314001030	Side support handle compl.	23
31	1	339137270	Hook	13
32	1	343448690	bit-depot 18 V	13
42	1	316053840	Switch complete with brush holder	45
95	1	343439680	Cover cap	11
850	1	627240000	Chuck Futuro Plus S1M Quick	
1001	1	338505830	Diagram	

