




Številka	Znesek	Številka za	Opis	PG
2	1	343447510	Chuck Futuro Plus S1M Quick	
5	1	343412640	poti-switch DX13-1004	22
7	1	316070640	Selector wheel compl.	22
9	1	343447510	Locking slide	11
12	1	343447500	Switch slide	11
13	1	316051650	Switch slide compl.	13
14	12	141113180	Self-tap. fill. h. screw	11
15	1	316068840	Gear-box compl.,SB Quick	35
20	1	338073500	Rating plate	12
21	1	338132260	Type label left,SB 18 LTX BL	12
22	1	338132320	Type label right,SB 18 LTX BL	12
23	3	339041310	insulating hose	11
24	1	343088210	Electronic unit, BS18LTXBL 2G Facelift	49
25	1	343447010	Insert	11
26	1	338129960	Indication label, CAS	12
40	1	339137270	Hook	13
41	1	314001560	Side support handle compl.	21
42	1	343448690	bit-depot 18 V	13
43	1	316069560	Motor compl.	43
44	1	316068720	housing w. cover	30
66	1	316066720	Latch compl.	14
67	2	342004180	Pressure spring	11
95	1	343439680	Cover cap	11
850	1	627240000	Chuck Futuro Plus S1M Quick	
1001	1	338506560	wiring diagram	