


Vacuum Cleaner Fuse



- The fuse protects the device socket from overload.
- It triggers if the socket is loaded with excessive current (5A or more) over an extended period of time. ➔ The white reset button (see fig.) pops out and disconnects the power supply and the vacuum cleaner's linked automatic power-on function.
- To reset the fuse, wait for a short period of time (approx. 15-30 sec.) before pushing the white reset button (see fig.) back to its original position.

Metabowerke GmbH
Metabo-Allee 1
72622 Nuertingen
Germany
www.metabo.com

metabo[®]

PROFESSIONAL POWER TOOL SOLUTIONS